



LIST OF CONTENTS

<u>. No</u>	<u>. Title</u>	<u>Page</u>
1.	SCHEMATICS	3
2.	IMPELLER TORQUE AND POWER MEASUREMENT	6
3.	FLUCTUATION ANALYSIS OF TORQUE DATA	9
4.	FFT OF TORQUE DATA	10
5.	EFFECT OF NO. OF IMPELLER BLADES	11
6.	EFFECT OF IMPELLER BLADE ANGLE	12
7.	EFFECT OF IMPELLER BLADE LENGTH	13
8.	EFFECT OF PARTICLE FRICTION COEFFICIENT	14
9.	EFFECT OF IMPELLER POSITION IN DEEP GRANULAR BED	15
10.	EFFECT OF PARTICLE SIZE	16
11.	NORMALIZATION BY PARTICLE DIAMETER	17
12.	EFFECT OF MATERIAL FILL HEIGHT	18
13.	SCALE-UP RELATIONSHIP	19
1/	IAMMPS	20

SCHEMATICS






DIMENSIONS

Value(mm)
100
10
45
128
25
2

MATERIALS

Variable	Value

Particle diameter 1, 2, and 5 mm
Partticle density 2.50 - 2.55g/ml
Friction coefficient 0.32
Mass of granular bed 300 - 900 g



THE BASE CASE

1. 2-mm
monodisperse,
cohesionless,
spherical, uncoated
red glass beads

3. (H/D) = 0.30.

5. Impeller: 4 blades pitched at 135° angle

2. 300 g of granular material loaded in the mixer


4. Shallow bed configuration

6. Blade length of 45 mm

IMPELLER TORQUE AND POWER MEASUREMENT

BLADE MOVEMENT INITIATED IN COUNTER-CLOCKWISE DIRECTION

SHEAR RATES CATEGORIZED INTO



Quasi-static. (y*<0.1) Intermediate regimes (y*>0.1).

y* = Dimensionless Shear rate


TORQUE CALCULATED FROM FORCE MEASURED BY LOAD CELL MULTIPLIED BY LEVER ARM LENGTH.

$$\vec{T} = \ell \times \vec{F}$$

AVERAGE SHEAR STRESS:

$$\langle au_{ heta r}
angle = rac{T}{2\pi R_{ ext{cyl}}^2 H}$$

POWER COMPOSED OF TWO COMPONENTS:



Motor power (P emp)

Power to move particle bed (P*)

$$P* = P - P emp$$

P = Power measured by Power meter

TORQUE AND POWER MEASUREMENTS

Dimensionless
Shear rate:


$$\gamma^* = \gamma^\circ \sqrt{rac{d}{g}}$$

Shear rate (s-1):

$$\gamma^{\circ} = \frac{2\pi \times Rotational \, Speed}{60}$$

Assumption made that power needed to run the motor under load can be separated from power needed to move the impeller.

Quasi-Static regime seen in Deep bed case, not in shallow Bed case.



FLUCTUATION ANALYSIS OF TORQUE DATA


Instantaneous torque values normalized by time-averaged torque at each blade rotational speed.

Torque Signal
$$_{
m recorded}$$
 recorded $T^*=rac{T}{\overline{}}$ $=rac{T}{\langle T
angle}$


T* = Dimensionless Normalized Torque T = Instantaneous torque <T> = Time averaged Torque

At 200 RPM, periodic burst behavior of torque fluctuations observed.

Attributed to expansion and compression states of granular bed in highest shear rate conditions.




FFT OF TORQUE DATA




Peaks corresponding to Rotational rate can be observed


Height of blade frequency peaks increases with rotational speed


Between 2-3 Hz natural frequency of particles are observed











10RPM 20RPM 60RPM


NO. OF IMPELLER BLADES

Higher radial velocity component of particle - 1 and 2 bladed mixers (better 3-D rrecirculation patterns)

Higher tangential velocity components of particle - 3 and 4 bladed mixers.

In 1 bladed mixer avg tangential contact force impeller blade exertss on particle is less.

Torque and power value fluctuations in 1 bladed mixer is higher because of asymmetry.



IMPELLER BLADE ANGLE


Decrease in average torque observed with increase in impeller blade angle.


Less variation in adjusted power readings.



Reason: Complexity in measuring power consumption due to two components

Assumption made that power needed to run motor with charged particles is equal to empty mixer







Average Torque (Nm)

Average adjusted powers at low shear rates show no obvious difference between the two blade lengths.

At higher shear rates, average adjusted power higher for 45-mm standard blades compared to 37.5-mm blades.

The total of IMPELLER BLADE LENGTH






MgSt-coated beads exhibit distinctly higher average torque compared to uncoated beads.

Standard deviations of torque values higher for MgSt-coated beads, indicating greater variability

PARTICLE FRICTION COEFFICIENT




IMPELLER POSITION IN DEEP GRANULAR BED

Quasi-static region observed at low shear rates in deep bed cases

Materials underneath impeller blades have limited influence on flow of grains in mixing system.

Minor differences observed between shallow and deep bed cases attributed to downward movement of particles caused by rotating impeller.




Her of PARTICLE SIZE

When Plotting wrt dimensionless shear rate, the datapoints for different bed sizes will not lie on same x axis

Highest average torque measured for 5-mm diameter particles, followed by 2-mm and 1-mm beads.

Quasi-static regime observed for 5-mm beads at low shear rates.



80 ■ 1-mm particles a) 2-mm particles 5-mm particles 60 20 10 15 20 5 25 0 y° (s⁻¹)

Time-averaged torque and average adjusted power normalized by particle diameter.


Normalized torque (<T>/d):


Normalized power (P*/d):

Highest for 1-mm particles, lower but similar for 2-mm and 5-mm particles.

NORMALIZATION BY PARTICLE DIAMETER

Granular flow = DImensionless inertial no. ∝ d






Circular lead weight placed on cardboard on top of glass beads to distribute normal load.

Lead weight equivalent to mass of 44 mm fill height used to simulate deeper beds.

HEIGHT HEIGHT




180 a) \bullet H/D = 0.30 AH/D = 0.60= H/D = 0.85× Effective H/D = 0.85 • Effective H/D = 1.04 120 60 × 0.2 0.5 0.0 0.1 0.3 0.4 y* (-) $T = 2\pi\mu\rho_{\rm bulk}gR_{\rm cvl}^2H^2$ $T \propto H \wedge 2$


Shallow bed exhibits different torque behavior due to surface particles forming heaps and valleys during rotation, affecting torque scaling relationship.


SCALE UP RELATIONSHIP


$$\stackrel{
ightarrow}{T}=2\pi R_{
m cyl}^2 H\langle au_{ heta r}
angle$$

$$\langle au_{ heta r} \rangle = \mu
ho_{ ext{bulk}} gH$$













Pour in 2D









THANK YOU!

KANISHQ SAHU

2022chb1049@iitrpr.ac.in

+91 9009730530